

## Cladding Installation Guide

- 1) Cladding is typically 3/4" to 1" thick.
- 2) Cladding is to be applied to a masonry vertical surface.  
I.E. block, concrete, & brown coat (do not apply over color coat).
- 3) Apply full flex thin set w/ notched trowel to clean sub-base and cladding.
- 4) Anchor with stainless screws and metal ties.
- 5) Grout joints (max .1/4") to be clean & fillers flush with grout and sponged clean.  
Joints to be damp with sponge and water before applying grout.

