

GROUT CHART

1 Bucket = 50 lbs	
Type of Precast	Approx. lineal feet based on 3/8" wide grout joint
Wall Caps W/ 10" BASE	100 LIN FT
Pool Coping 12" BASE	100 LIN FT
Pool Coping 18" BASE	65 LIN FT
Balusters W/ BASE & CAP	20 LIN FT
Columns 8 FT High	3 to 4 Columns

INSTRUCTIONS: JUST ADD WATER DO NOT ADD EXCESSIVE WATER

Pacific Stone Grout Application

1. Grout joints should be clean cool and moist (mornings are best grouting times)
2. Too much liquid (soupy texture) will cause grout to crack and fail quickly.
3. Apply with grout bag. Apply to bottom of coping and 3/8" above top of coping, wait 3 to 10 minutes (depending on weather) then with small margin trowel push excess down into grout joint. Wait 3 to 5 minutes and then sponge to make flush.

RADIUS INFORMATION

WALL CAPS	180 DEGREES	360 DEGREES	INSIDE LENGTH
RADIUS 12	(2) PIECES	(4) PIECES	90 DEGREES
RADIUS 18	(3) PIECES	(6) PIECES	18-3/4" LENGTH
RADIUS 24	(4) PIECES (3) PIECES	(8) PIECES (6) PIECES	18-5/8" LENGTH 24-3/4" LENGTH
RADIUS 36	(5) PIECES	(10) PIECES	22-1/2" LENGTH
RADIUS 42	(6) PIECES	(12) PIECES	21-3/4" LENGTH
RADIUS 48	(6) PIECES	(12) PIECES	24-3/4" LENGTH
RADIUS 54	(7) PIECES	(14) PIECES	24" LENGTH
RADIUS 60	(8) PIECES	(16) PIECES	23-1/2" LENGTH
RADIUS 72	(9) PIECES	(18) PIECES	24-3/4" LENGTH
RADIUS 84	(11) PIECES	(22) PIECES	23-3/4" LENGTH
RADIUS 96	(12) PIECES	(24) PIECES	24-3/4" LENGTH
RADIUS 120	(15) PIECES	(30) PIECES	24-3/4" LENGTH
RADIUS 144	(18) PIECES	(36) PIECES	24-3/4" LENGTH
RADIUS 240	(30) PIECES	(60) PIECES	24-3/4" LENGTH
RADIUS 360	(45) PIECES	(90) PIECES	24-3/4" LENGTH

2/09/16

Notes:

1. WALL CAPS RADIUS MEASURED TO THE INSIDE OF THE CAP
2. COPING AND STAIR TREADS RADIUS MEASURED TO BULLNOSE SIDE